

Quality Test Report

(Page 1 of 4)

March 2, 2020

BOKEN QUALITY EVALUATION INSTITUTE

BOKEN

1-6-24 Chikko, Minato-ku, Osaka-shi,
Osaka 552-0021, Japan

TEL.+81-6-6577-0200/FAX.+81-6-6577-0210

NAVY

Number of Item : 2

Test Item : The test of the antiviral efficacy

Test Method : ISO18184 : 2019 Textiles – Determination of antiviral activity of textile products

Infective titre measurement : Plaque assay

Washing Method : "Washing method of textile products with SEK mark" specified by Japan Textile
Evaluation Technology Council - Standard washing method

Test virus : Influenza A virus (H3N2) : ATCC VR-1679

Test Result :

Test sample		The common logarithm average of infectivity titer value		The antiviral activity value $\lg(V_a) - \lg(V_c)$
Standard cloth	Immediately after inoculation	$\lg(V_a)$	6.38	—————
	After 2h	$\lg(V_b)$	5.98	—————
Knit fabric:Pique CM40/2 NAVY (original)		$\lg(V_c)$	2.30	4.1
" (after fifteen wash)		$\lg(V_c)$	5.65	0.7

Notice – This test result is applied to the submitted sample, not to the lot.
Unauthorized reproduction, in whole or in part, is strictly prohibited.



BK20024678354

Quality Test Report

Test Report No. BK20024678354

(24419002879-1)

(Page 2 of 4)

Test Result :

Verification of this test		Criterion value	Test sample	Test result	Verification
Test item					
a	The virus infective titer of inoculated concentration for the test (PFU/mL)	$\geq 10^7$	—————	1.4×10^7	Pass
b	Verification of cytotoxic effect	No damage	Knit fabric:Pique CM40/2 NAVY (original)	No damage	Pass
			〃 (after fifteen wash)	No damage	Pass
	Verification of cell sensitivity to virus and inactivation of antiviral activity	≤ 0.5	Knit fabric:Pique CM40/2 NAVY (original)	0.0	Pass
			〃 (after fifteen wash)	0.0	Pass
c	Logarithm reduction value of infective titer of control specimen	≤ 1.0	—————	0.4	Pass

BOKEN QUALITY EVALUATION INSTITUTE

Osaka Functional Textile Testing Center

Supervised by *Yoshihiko Muremaki*

Notice - This test result is applied to the submitted sample, not to the lot.
Unauthorized reproduction, in whole or in part, is strictly prohibited.



BK20024678354

Quality Test Report

ORIGINAL

Test Report No. BK20024678354

(24419002879-1) (Page 3 of 4)

Applicant:

March 2, 2020

Test results to submitted sample are as follows.

Reception Date : February 13, 2020

Item Name : Knit fabric:Pique CM40/2

NAVY

Number of Item : 2

Test Item : The test of the antiviral efficacy

Test Method : ISO18184 : 2019 Textiles – Determination of antiviral activity of textile products

Infective titre measurement : Plaque assay

Washing Method : "Washing method of textile products with SEK mark" specified by Japan Textile
Evaluation Technology Council – Standard washing method

Test virus : Influenza A virus (H1N1) : ATCC VR-1469

Test Result :

BOKEN QUALITY EVALUATION INSTITUTE

BOKEN

Osaka Functional Textile
Testing Center

1-6-24 Chikko, Minato-ku, Osaka-shi,
Osaka 552-0021, Japan

TEL.+81-6-6577-0200/FAX.+81-6-6577-0210

Test sample		The common logarithm average of infectivity titer value		The antiviral activity value $\lg(V_a) - \lg(V_c)$
Standard cloth	Immediately after inoculation	$\lg(V_a)$	6.38	_____
	After 2h	$\lg(V_b)$	5.66	_____
Knit fabric:Pique CM40/2 NAVY (original)		$\lg(V_c)$	2.30	4.1
" " (after fifteen wash)		$\lg(V_c)$	5.20	1.2

Notice - This test result is applied to the submitted sample, not to the lot.
Unauthorized reproduction, in whole or in part, is strictly prohibited.



BK20024678354

Quality Test Report

Test Report No. BK20024678354

(24419002879-1)

(Page 4 of 4)

Test Result :

Verification of this test		Criterion value	Test sample	Test result	Verification
Test item					
a	The virus infective titer of inoculated concentration for the test (PFU/mL)	$\geq 10^7$	—————	1.4×10^7	Pass
b	Verification of cytotoxic effect	No damage	Knit fabric:Pique CM40/2 NAVY (original)	No damage	Pass
			// (after fifteen wash)	No damage	Pass
	Verification of cell sensitivity to virus and inactivation of antiviral activity	≤ 0.5	Knit fabric:Pique CM40/2 NAVY (original)	0.0	Pass
			// (after fifteen wash)	0.0	Pass
c	Logarithm reduction value of infective titer of control specimen	≤ 1.0	—————	0.7	Pass

BOKEN QUALITY EVALUATION INSTITUTE

Osaka Functional Textile Testing Center

Supervised by *Yoshihiko Muramatsu*

Notice - This test result is applied to the submitted sample, not to the lot.
Unauthorized reproduction, in whole or in part, is strictly prohibited.



BK20024678354